



# Dell Inspiron 910 Battery Replacement

This guide will show you how to replace the battery from the laptop.

Written By: Kyle Beekman



## INTRODUCTION

Before starting the procedures make sure the laptop is turned off and unplugged from the charger.

## Step 1 — Remove Battery



- Turn the laptop over to where the battery is facing upwards and towards you.
- Locate the release tabs located on either sides of the battery.
- Push the release tabs toward the center of the device.
- Remove the battery.

## Step 2 — Insert Replacement Battery



- Take the replacement battery and insert it into the laptop the same way the old battery was removed.
- Slide the release tabs back into place.

Your computer may now be turned back on.

This document was last generated on 2017-10-13 11:44:26 PM.